

ELV Control

Lighting Control System	Model	Page
Lighting Interface Box	DLC29, DLC39, DLC44	2
Lighting Control Box	DL04H, DL06H, DL09H	3
Lighting Control System Connection Diagram		4
ELV Junction Box	DAL21, DAL28	5
ELV Junction Box	DAL32, DAL40	6

Push Button	Model	Page
Door Release Button	DL160D	7
Manual Push Button	DLB16C, DLB23D	8
Push Button	DL05C, DL05D, DL05S	9
Push Button Connection Diagram	DL05C, DL05D, DL05S	10
Push Button	DL03R, DL03S, DL03G	11
